

森林漫步 正

145mm

森林漫步 背

215mm

red kite

IMPORTANT!

KEEP FOR FUTURE REFERENCE


Read these instructions carefully before use.

Your child's safety may be affected if you do not follow these instructions.

Instruction leaflet

Sit Me Up

Woodland Walks



Suitable from 9 months

Manufactured By: The Red Kite Baby Co Ltd 35 Lavenham Road, Beeches Industrial Estate, Yate, Bristol, BS37 5QX, UK.

Authorised Representative: Mum n Me, Triq is-Suq, Zejtun, ZTN1420, Malta.

EN 71. Colours and fabrics may vary.

Customer Care: www.redkitebaby.com

UK
CA
CE

INSTRUCTIONS

1. Fully unfold the fabric cover.
2. Place the inner tube inside the fabric cover (if not already inside the cover).
3. Inflate the inner tube by taking the stopper out of the valve and pulling the valve out of the tube by approx 2cm. Squeeze the base of the valve and blow into the opening. Replace stopper and push back down so that it is level with the tube.
4. Attach the tray to the Velcro located on both sides of the seat.

SAFETY WARNINGS

- **KEEP AWAY FROM FIRE!**
 - Minimum recommended age for use: 9 months.
 - Do not use until your baby is fully able to support its head and sit up unaided.
 - Only use this product under full adult supervision.
 - Do not leave a child unattended in this product. Always keep your child in view.
 - Position the Sit Me Up on a level and stable floor surface.
 - Keep the Sit Me Up away from trailing cords and flexes.
 - Do not use for more than one child at a time.
 - Your child's safety is your responsibility.
 - Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the Sit Me Up.
 - Keep the Sit Me Up away from sharp objects.
 - Do not carry a baby in the Sit Me Up.
 - Check the inflatable ring and fabric cover for signs of damage.
 - Stop using the Sit Me Up if you notice any signs of damage and or deterioration.
 - This product must not be used as a car seat, in a bath (or in any water).
 - This product is a toy and must not be used as a support or restraint system or for any other purpose than supervised play.
 - Adult assembly required.

WASHING INSTRUCTIONS

- Cover: Surface wash only with a mild detergent solution. Air dry. Do not bleach. Do not iron. Do not tumble dry. Do not dry clean.
- Inner tube: Surface clean with a mild detergent solution only. Air dry. Do not bleach. Do not iron. Do not tumble dry. Do not dry clean.